



DS-K3B530X Series Swing Barrier with Module

User Manual

Legal Information

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

- This product can only enjoy the after-sales service support in the country or region where the purchase is made.
- If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.



Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR

IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Data Protection

- To protect data, the development of Hikvision Products incorporates privacy by design principles. For example, for Products with facial recognition features, biometrics data is stored in your Products with encryption method; for fingerprint Products, only fingerprint template will be saved, which is impossible to reconstruct a fingerprint image.
- As a data controller/processor, you may process personal data, including collection, storage, use, processing, disclosure, deletion, etc. You are advised to pay attention to and comply with applicable laws and regulations related to the protection of personal data, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and the assessments of the effectiveness of your security controls.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Regulatory Information

FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed

under the EMC Directive 2014/30/EU, RE Directive 2014/53/EU, the RoHS Directive 2011/65/EU



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info



Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into Dangers and Cautions:

Dangers: Neglecting any of the warnings may cause serious injury or death.

Cautions: Neglecting any of the cautions may cause injury or equipment damage.

| | |
|---|---|
|  |  |
| Dangers: Follow these safeguards to prevent serious injury or death. | Cautions: Follow these precautions to prevent potential injury or material damage. |

Danger:

- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Please use the power adapter, which is provided by normal company. The power consumption cannot be less than the required value.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
If the top caps should be open and the device should be powered on for maintenance, make sure:
 1. Power off the fan to prevent the operator from getting injured accidentally.
 2. Do not touch bare high-voltage components.
 3. Make sure the switch's wiring sequence is correct after maintenance.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.
- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.
- Do not ingest battery, Chemical Burn Hazard.
This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

Cautions:

- Stainless steel may be corroded in some circumstances. You need to clean and care the device by using the stainless steel cleaner. It is suggested to clean the device every month.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.
- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Biometric recognition products are not completely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.
- Do not stay in the lane when the device is rebooting.
- RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.
- The instructions shall require connection of the equipment protective earthing conductor to the installation protective earthing conductor.

Available Models

| Product Name | Model | Description |
|---------------|-----------------------------|-----------------|
| Swing Barrier | DS-K3B530LX-L/DS-K3B530X-L/ | Left Pedestal |
| | DS-K3B530LX-M/DS-K3B530X-M | Middle Pedestal |
| | DS-K3B530LX-R/DS-K3B530X-R | Right Pedestal |

Scan the QR code below to view the installation and wiring video.



Figure 1-1 Video QR Code

Contents

| | |
|--|-----------|
| Chapter 1 Overview | 1 |
| 1.1 Introduction | 1 |
| 1.2 Main Features | 1 |
| Chapter 2 System Wiring | 3 |
| Chapter 3 Install Pedestals | 6 |
| Chapter 4 Install Card Reader Module (Optional) | 11 |
| Chapter 5 Install QR Code Module (Optional) | 12 |
| Chapter 6 General Wiring | 14 |
| 6.1 Components Introduction | 14 |
| 6.2 Wiring | 16 |
| 6.3 Terminal Description | 17 |
| 6.3.1 General Wiring | 17 |
| 6.3.2 Main Lane Control Board Terminal Description | 18 |
| 6.3.3 Sub Lane Control Board Terminal Description | 19 |
| 6.3.4 Access Control Board Terminal Description (Optional) | 20 |
| 6.3.5 Main Extended Interface Board Terminal Description | 22 |
| 6.3.6 Card Reader Module Wiring (Optional) | 23 |
| 6.3.7 QR Code Module Wiring | 25 |
| 6.3.8 Lane Status Indicator Board | 27 |
| 6.3.9 Authentication Indicator Board Terminal Description | 27 |
| 6.3.10 RS-485 Wiring | 28 |
| 6.3.11 RS-232 Wiring | 28 |
| 6.3.12 Alarm Input Wiring | 29 |
| 6.3.13 Exit Button Wiring | 29 |
| 6.4 Device Settings via Button | 30 |
| 6.4.1 Configuration via Button | 32 |


| | |
|---|-----------|
| 6.4.2 Study Mode Settings | 35 |
| 6.4.3 Keyfob Pairing | 37 |
| 6.4.4 Initialize Device | 39 |
| Chapter 7 Activation | 40 |
| 7.1 Activate via Web Browser | 40 |
| 7.2 Activate via Mobile Web | 40 |
| 7.3 Activate via SADP | 41 |
| 7.4 Activate Device via iVMS-4200 Client Software | 42 |
| Chapter 8 Operation via Web Browser | 44 |
| 8.1 Login | 44 |
| 8.2 Overview | 44 |
| 8.3 Person Management | 45 |
| 8.4 Search Event | 47 |
| 8.5 Configuration | 49 |
| 8.5.1 View Device Information | 49 |
| 8.5.2 Set Time | 49 |
| 8.5.3 Set DST | 50 |
| 8.5.4 Change Administrator's Password | 50 |
| 8.5.5 Online Users | 50 |
| 8.5.6 View Device Arming/Disarming Information | 51 |
| 8.5.7 Network Settings | 51 |
| 8.5.8 Set Audio Parameters | 54 |
| 8.5.9 Event Linkage | 54 |
| 8.5.10 Access Control Settings | 56 |
| 8.5.11 Turnstile | 61 |
| 8.5.12 Card Settings | 65 |
| 8.5.13 Set Privacy Parameters | 66 |
| 8.5.14 Prompt Schedule | 66 |

| | |
|--|-----------|
| 8.5.15 Upgrade and Maintenance | 68 |
| 8.5.16 Device Debugging | 69 |
| 8.5.17 Component Status | 70 |
| 8.5.18 Log Query | 71 |
| 8.5.19 Certificate Management | 71 |
| Chapter 9 Configure the Device via the Mobile Web | 73 |
| 9.1 Login | 73 |
| 9.2 Overview | 73 |
| 9.3 Configuration | 75 |
| 9.3.1 Turnstile Basic Settings | 75 |
| 9.3.2 Person Management | 76 |
| 9.3.3 Keyfob Settings | 78 |
| 9.3.4 Light Settings | 79 |
| 9.3.5 View Device Basic Information | 81 |
| 9.3.6 Time Settings | 82 |
| 9.3.7 User Management | 83 |
| 9.3.8 Network | 83 |
| 9.3.9 Event Search | 87 |
| 9.3.10 Set Audio | 88 |
| 9.3.11 Access Control Settings | 89 |
| 9.3.12 Upgrade and Maintenance | 95 |
| 9.3.13 View User Document | 96 |
| 9.3.14 View Open Source Software License on Mobile Web | 96 |
| 9.3.15 Log Out | 96 |
| Chapter 10 Other Platforms to Configure | 97 |
| Appendix A. DIP Switch | 98 |
| A.1 DIP Switch Description | 98 |
| A.2 DIP Switch Corresponded Functions | 98 |

Appendix B. Button Configuration Description 99
Appendix C. Event and Alarm Type 111
Appendix D. Table of Audio Index Related Content 112
Appendix E. Error Code Description 113

Chapter 1 Overview

1.1 Introduction



The Swing barrier with 14 IR lights is designed to detect unauthorized entrance or exit. By adopting the swing barrier integratedly with the access control system, person should authenticate to pass through the lane via swiping IC or ID card, scanning QR code, etc. It is widely used in attractions, stadiums, construction sites, residences, etc.

1.2 Main Features

- Supports control mode, inductive mode, free passing mode, remain open mode and remain closed mode in both entrance and exit direction.
- Anti-forced-accessing
The barrier will react according to soft mode or guarding mode when confronting forced-accessing.
- Self-detection, self-diagnostics, and automatic alarm
- Audible and visual alarm will be triggered when detecting intrusion, tailgating, reverse passing, and climbing over barrier.
- LED indicates the entrance/exit and passing status
- Fire alarm passing
When the fire alarm is triggered, the barrier will be open automatically for emergency evacuation.
- Valid passing duration settings

System will cancel the passing permission if a person does not pass through the lane within the valid passing duration.

- Bidirectional (Entrance/Exit) lane
The barrier opening and closing speed can be configured according to the visitor flow.
- TCP/IP network communication
The communication data is specially encrypted to relieve the concern of privacy leak.
- Permissions validation and anti-tailgating
- Remote barrier opening via keyfob and broadcasting via loudspeaker (custom broadcasting context is supported when installed with access control board).


Chapter 2 System Wiring

The preparation before installation and general wiring.

Steps

Note

- The device should be installed concrete surface or other flat non-flammable surface.
- If the installation area is too close to the wall, make sure the distance between the pedestal and the wall should be no less than 20 mm (60 mm if with face recognition terminals), or you cannot open the pedestal's top panel or might cause damage to devices.



- The dimension is as follows.




Figure 2-1 Dimension

-
1. Draw a central line on the installation surface of the left or right pedestal.
 2. Draw other parallel lines for installing the other pedestals.
-

 **Note**

The distance between the nearest two line is $L + 272$ mm. L represents the lane width.

3. Slot on the installation surface and dig installation holes. Put 4 expansion bolts of M12*120 for each pedestal.




Figure 2-2 Hole Position and System Wiring

4. Bury cables. Each lane buries 1 high voltage cable and 1 low voltage cable. For details, see the system wiring diagram of step 3.

Note

- High voltage: AC power input
Low voltage: interconnecting cable (communication cable and 24 V power cable) and network communication cable
- The supplied 24 V power cable length is 5 m and the communication cable length is 3 m.
- The suggested inner diameter of the low voltage conduit is larger than 30 mm.
- If you want to bury both of the AC power cord and the low voltage cable, the two cables should be in separated conduits to avoid interference.
- If more peripherals are required to connect, you should increase the conduit diameter or bury another conduit for the external cables.
- The external AC power cord should be double-insulated.
- The network cable must be CAT5e or the network cable has better performance.

Chapter 3 Install Pedestals

Before You Start

Prepare for the installation tools, check the device and the accessories, and clear the installation base.

Steps

Note

- The device should be installed on the concrete surface or other flat non-flammable surfaces.
 - Make sure the device is powered off during installation and other operations.
 - The installation tools are put inside the package of the pedestal.
-

1. Prepare for the installation tools, check the components, and prepare for the installation base.
2. Remove 4 screws of each pedestal that fix the 2 side panels.




Figure 3-1 Remove Side Panel Screws

3. Remove the side panels and move the pedestals to the corresponded positions according to the entrance and exit marks on the pedestals.




Figure 3-2 Remove Side Panel Screws

Note


For detailed information about system wiring, see ***System Wiring*** .

4. Secure the pedestals with expansion bolts and fix the side panels to its original position with screws.

Note

- Do not immerse the pedestal in the water. In special circumstances, the immersed height should be no more than 150 mm.

5. Remove 3 screws to open each maintenance door for cable wiring.






Figure 3-3 Remove Maintenance Door

 **Note**

For detailed information about cables, see [*General Wiring*](#).

Chapter 4 Install Card Reader Module (Optional)

If the device is not install the card reader module, you can select to install the card reader module on the turnstile for authentication passing.

Steps

1. Open the cover.
2. Use 3 screws (M3-6) to fix the card reader on the bracket.




Figure 4-1 Fix Card Reader on Bracket

3. Install the card reader module in the area by 4 screws.
4. Install the coil in the cover.
5. Install the cover back.

Note

The image is for instance. Please refer to actual product.




Figure 4-2 Install Card Reader Module

Chapter 5 Install QR Code Module (Optional)

If the device is not install the QR code module, you can select to install the module on the turnstile for QR code authentication.

Steps

1. Open the cover.
2. Install the QR code module in the area by 4 screws.
3. Install the cover back.



Note

The image is for instance. Please refer to actual product.




Figure 5-1 Install QR Code Module

Chapter 6 General Wiring

Note

- When you should maintain or disassemble the high voltage modules, you should remove the entire high voltage modules and maintain it outside the turnstile. You should unplug the cables that connected to the peripherals before maintenance to avoid destroy of the device.
 - When disassembling the high voltage module, you should disconnect the power to avoid injury.
 - If only wiring is needed without maintenance, do not remove the high voltage modules.
 - The switch and the main lane control board are already connected. The 14 AWG cable to connect between the AC electric supply and the switch should be purchased separately.
 - 2 interconnecting cables are supplied: 24 V Power Cable and Communication Cable.
24 V Power Cable: 5 m long, which is in the middle and right pedestal.
Communication Cable: 4 m long, CAT5e, which is in the package of middle and right pedestal.
-

6.1 Components Introduction

By default, basic components of the turnstile are connected well. The pedestals can communicate by wiring the interconnecting cables. And the turnstile supports wiring the AC electric supply for the whole system's power supply.

Note

The voltage fluctuation of the electric supply is between 100 VAC and 240 VAC, 50 to 60 Hz.

The picture displayed below describes the serial port on the entrance and exit direction.




Figure 6-1 Serial Port

The picture displayed below describes the IR sending/receiving module and their corresponding number on the pedestal.




Figure 6-2 IR Sending/Receiving Module Position

Note

Standing at the entrance position in the lane, the IR modules on your left are the IR sending modules, the ones on your right are the IR receiving modules.

6.2 Wiring

Scan the QR code to watch the guide video.



6.3 Terminal Description

6.3.1 General Wiring

The general wiring of lane control board, access control board and extended interface board.




Figure 6-3 General Wiring


Note

- The power cable from power supply to the main lane control board has been connected. You will need to prepare the 14AWG power cable to connect the AC power input to power supply.
 - The supplied 2 interconnecting cables need connecting on-site:
 1. 24 V power cable of 14 AWG. The cable is 5 m in length and put inside the right/middle pedestal at the exit.
 2. CAT5e Communication cable. The cable is 3 m in length and put inside the package of the right/middle pedestal.
 - The ① and ② or ③ and ④ refer to the two sides of a same board.
 - Barrier opens at the entrance/exit: connect to BTN1/BTN2 and GND.
-

6.3.2 Main Lane Control Board Terminal Description

The main lane control board contains interconnecting interface, access control board interface, fire input interface, exit button interface, 12 VDC output interface, 24 VDC input interface, fan interface, communication interface, encoder interface, power supply interface for motor, supercapacitor interface, main brake interface, adaptor interface and tamper interface.

The picture displayed below is the main lane control board diagram.



Main Lane Control Board




Figure 6-4 Main Lane Control Board Terminals

6.3.3 Sub Lane Control Board Terminal Description

The sub lane control board contains interconnecting interface, BUS interface, exit button interface, 12 VDC output interface, 24 VDC input interface, fan interface, communication interface, encoder interface, power supply interface for motor, supercapacitor interface, sub brake interface, adaptor interface and tamper interface.

The picture displayed below is the sub lane control board diagram.




Figure 6-5 Sub Lane Control Board Terminals

6.3.4 Access Control Board Terminal Description (Optional)

Access control board is mainly used for authority identification in places with high security levels such as public security or judicial place, external device accessing, and communication with the upper platform and lane controller.




Figure 6-6 Access Control Board

Note

- RS-485A corresponds to port 5 on web and is for QR code scanner connection at entrance by default; RS-485C corresponds to port 7 on web and is for card reader connection at entrance by default.
- The SOC serial port is for maintenance and debugging use only.
- Press the Reset button for 5 s and the device will start to restore to factory settings.
- The DIP switch is for study mode setting and keyfob pairing. For detailed information about the DIP switch, see *DIP Switch Description*.

The wiring diagram of extended interface of access control board is shown as follows.




Figure 6-7 Wiring Diagram of BUS3 Interface

Note

RS-232A corresponds to port 1 on web.

6.3.5 Main Extended Interface Board Terminal Description

The main extended interface board contains the sub-1G antenna interface, barrier light interface, loudspeaker interface, debugging port, Wiegand/exit button interface, 5 VDC output and communication interface.




Figure 6-8 Main Extended Interface Board Terminal

Note

When the device is installed with access control board, the loudspeaker shall be connected to the access control board. If not, the loudspeaker shall be connected to the main extended interface board.

6.3.6 Card Reader Module Wiring (Optional)

The card reader module can be connected to the access control board or interface board via RS-485 interface.




Figure 6-9 Card Reader Module




Figure 6-10 Wiring Diagram (With RS-485)

Note

- The wiring here is for reference only. For different turnstiles, the connection interface varies.
- RS-485 parameters cannot be configured. By default, the communication bitrate is 19200, the data bit is 8, the stop bit is 1, no odd even check.




Figure 6-11 Wiring Diagram (With RS-485)

Note

The wiring here is for reference only. For different turnstiles, the connection interface varies.

6.3.7 QR Code Module Wiring

The QR code module can be connected to the access control board or interface board via RS-485 interface..




Figure 6-12 QR Code Module Wiring (With RS-485)

Note

- The wiring here is for reference only. For different turnstiles, the connection interface varies.
- RS-485 parameters cannot be configured. By default, the communication bitrate is 19200, the data bit is 8, the stop bit is 1, no odd even check.




Figure 6-13 QR Code Module Wiring (With USB)

Note







The wiring here is for reference only. For different turnstiles, the connection interface varies.

6.3.8 Lane Status Indicator Board

For details about lane status indicator position, see .

Lane status indicator board in different pedestals are shown as follows.

Table 6-1 Lane Status Indicator Board

| Pedestal | Entrance | Exit |
|-----------------|---|---|
| Right Pedestal |  |  |
| Left Pedestal |  |  |
| Middle Pedestal |  |  |

6.3.9 Authentication Indicator Board Terminal Description




Figure 6-14 Authentication Indicator Board

The authentication indicator board is connected to the LED1 terminal of main lane control board.

6.3.10 RS-485 Wiring

The RS-485 interfaces on the access control board and sub extended interface board are suggested to connect with the face recognition module or the card reader. Here takes connecting with a card reader as an example.

Note

- There are 2 RS-485 interfaces on the access control board for entrance. Refer to ***Access Control Board Terminal Description (Optional)*** for details.
There are 2 RS-485 interfaces on the sub extended interface board for exit. Refer to for details.
 - If connecting the RS-485 with a card reader, by default, the DIP switch of the card reader should be set as follows:
 - For entrance, set the No.1 of the 4-digit DIP switch to ON side.
 - For exit, set the No.3 of the 4-digit DIP switch to ON side.
 - If there are other RS-485 devices connecting, the ID of the RS-485 cannot be conflicted.
 - The connected 12 V power interface for the face recognition terminal cannot be connected with other 12 V devices.
-




Figure 6-15 Wiring RS-485

6.3.11 RS-232 Wiring

Note

- There is 1 RS-232 interface on the extended interface of access control board, see ***Access Control Board Terminal Description (Optional)*** . The RS-232A corresponds to UART 1 on web.
 - There is 1 RS-232 interface on the sub extended interface board, see . The RS-232B corresponds to UART 2 on web.
The RS-232C interface is reserved.
-




Figure 6-16 RS-232 Wiring

6.3.12 Alarm Input Wiring

On the main lane control board, you can wire the fire alarm input interface.




Figure 6-17 Remaining Open




Figure 6-18 Remaining Closed

6.3.13 Exit Button Wiring

The main and sub lane control board each has 1 button interface, which can be connected to exit button or face recognition device.




Figure 6-19 Exit Button Wiring

Note

- The face recognition devices are powered via 12 VDC power output interface of the main and sub lane control board.
- Barrier open at the entrance: connect to BTN1 and GND.
- Barrier open at the exit: connect to BTN2 and GND.

6.4 Device Settings via Button

You can configure the device via button on the main lane control board or the DIP switch on the access control board.

| Function | Main Lane Control Board & Loudspeaker (Connected to Main Extended Interface Board) | Main Lane Control Board & Access Control Board & Loudspeaker (Connected to Access Control Board) |
|-------------------|--|--|
| Working Mode | | |
| Normal/Study Mode | Configure via button (refer to <i>Set Study Mode via Button</i>) | Configure via DIP switch (refer to <i>Set Study Mode via DIP Switch (Optional)</i>) |
| keyfob Pairing | Configure via button (refer to <i>Pair Keyfob via Button</i>) | Configure via DIP switch (refer to <i>Pair Keyfob via DIP Switch (Optional)</i>) |
| Passing Mode | Configure via button | Configure via button/web |

DS-K3B530X Series Swing Barrier with Module User Manual

| Function | Main Lane Control Board & Loudspeaker (Connected to Main Extended Interface Board) | Main Lane Control Board & Access Control Board & Loudspeaker (Connected to Access Control Board) |
|--------------------------------|--|--|
| Memory Mode | Configure via button | Configure via button/web |
| Control Mode | Configure via button | Configure via button/web |
| Application Mode | Configure via button | Configure via button |
| Parameter Settings | | |
| Barrier Opening Speed | Configure via button | Configure via button/web |
| Barrier Closing Speed | Configure via button | Configure via button/web |
| Card Reading on the Alarm Area | Configure via button | Configure via button/web |
| Enter Duration | Configure via button | Configure via button/web |
| Exit Duration | Configure via button | Configure via button/web |
| IR Sensing Duration | Configure via button | Configure via button/web |
| Intrusion Duration | Configure via button | Configure via button/web |
| Overstay Duration | Configure via button | Configure via button/web |
| Delay Time for Barrier Closing | Configure via button | Configure via button/web |
| Barrier Recover Duration | Configure via button | Configure via button |
| Volume Adjustment | Configure via button | Configure via button |
| Barrier Material | Configure via button | Configure via button/web |
| Barrier Length | Configure via button | Configure via button/web |
| Barrier Height | Configure via button | Configure via button/web |
| Brake | Configure via button | Configure via button |
| Brake Angle | Configure via button | Configure via button |
| IR Sensing | Configure via button | Configure via button/web |
| Fan | Configure via button | Configure via button |
| Light Brightness | Configure via button | Configure via button/web |
| Restore to Default | Configure via button | Configure via button/web |
| Voice Prompt | | |

| Function | Main Lane Control Board & Loudspeaker (Connected to Main Extended Interface Board) | Main Lane Control Board & Access Control Board & Loudspeaker (Connected to Access Control Board) |
|----------------------------|--|--|
| Climbing over Barrier | Enable or disable via button | Enable or disable via button |
| Reverse Passing | Enable or disable via button | Enable or disable via button |
| Exceeding Passing Duration | Enable or disable via button | Enable or disable via button |
| Intrusion Alarm | Enable or disable via button | Enable or disable via button |
| Tailgating Alarm | Enable or disable via button | Enable or disable via button |
| Overstaying Alarm | Enable or disable via button | Enable or disable via button |
| Motor Inspection | Configure via button | Configure via button |
| Self-check Voice Prompt | Enable or disable via button | Enable or disable via button |
| Study Mode Voice Prompt | Enable or disable via button | Enable or disable via button |

 **Note**

- Refer to ***Button Configuration Description*** for detailed information.
- If the device is not equipped with access control board, the loudspeaker shall be connected to the main extended interface board.
- If the device is equipped with access control board, the loudspeaker shall be connected to the access control board. You can set custom broadcasting context via web. For details, see ***Prompt Schedule*** .

6.4.1 Configuration via Button

Button Description




Figure 6-20 Button

Exit Button

- Press to open the barrier from the entrance position.
- Double press to open the barrier from the exit position.

Parameter Configuration Button

- LEFT: Press to add 10 to configuration data.
- RIGHT: Press to add 1 configuration data.
- CANCEL: Return to the Level-1 menu, or exit Level-1 menu.
- OK: Confirm the settings, or enter configuration mode, or enter the Level-2 menu.



Note

- Configuration No. is displayed by two digital tubes.
- Level-1 Menu: If the decimal point on the right is on, it indicates the Level-1 menu. The number represents the configuration No.
- Level-2 Menu: If the decimal point in the middle is on, it indicates the level-2 menu. The number represents the configuration No.

Button Configuration Procedure

Here takes setting intrusion duration to 12 s as example:




Figure 6-21 Procedure

Steps:

1. Hold **OK** button for 3 s until one beep occurs. The device enter the configuration mode. Level 1 menu lights up. The display screen displays the configuration No. **1**.
2. In the Level-1 menu, press **LEFT** (plus 10) once and press **RIGHT** (plus 1) twice to set the configuration No. to 12. Press **OK** to save settings and the enter the level-2 menu. Or you can press **CANCEL** to exit the current menu, or conduct no operation for 5 s to cancel configuration and exit the current menu.
3. After enter the level 2 menu, press **LEFT** (plus 10) once and **RIGHT** (plus 1) twice to set the configuration No. to 12. Press **OK** to save the settings. Or you can press **CANCEL** to exit the current menu, or conduct no operation for 5 s to cancel configuration and exit the current menu.

 **Note**

- The configuration No. will display in a cycle.
 - Each configuration No. refers to a function. For details about the configuration No. and its related function, see **Button Configuration Description** .
-

6.4.2 Study Mode Settings

Set the closed position of the device barrier.

Set Study Mode via Button

Enter the study mode through button configuration to set the closed position of the device barrier.

Steps

 **Note**

- If the device is equipped with access control board, you can set study mode via DIP switch on the access control board only.
 - For details about button's operation, see **Configuration via Button** .
 - For details about the configuration No. and its related function, see **Button Configuration Description** .
-

1. Enter the study mode.
 - 1) Enter the configuration mode.
 - 2) Set the configuration No. in Level-1 to **1**. The device will enter the study mode.
 - 3) Set the configuration No. in the Level-2 menu to **2**. The device will enter the study mode.
2. Power off the device and swing the barrier until it is vertical to the pedestal.
3. Power on the device.

The device will remember the current position automatically.
4. Reboot the device when you hear **Study accomplished. Please reboot.**

Set Study Mode via DIP Switch (Optional)

Enter the study mode through DIP switching to set the closed position of the device barrier.

Steps

1. Set the No.1 of the 2-digit DIP switch on the access control board to ON by referring the following figure to enter the study mode.




Figure 6-22 DIP Switch Location




Figure 6-23 Study Mode

2. Adjust the closed position of the barrier.
3. Power on the device.
The device will remember the current position (closed position) automatically.
4. Power off the device.
5. Set the No.1 switches of the 2-digit DIP Switch on the main user extended interface board by referring to the following figure.




Figure 6-24 Normal Mode

6. Power on the device again.

 **Note**

For details about the DIP switch value and meaning, see *DIP Switch Description*.

The barrier will open automatically and turns back to the closed position. At this circumstance, the device enters the normal mode.

6.4.3 Keyfob Pairing

Pair keyfob via button or DIP switch.

Pair Keyfob via Button

Pair the keyfob to the device via button to open/close the barrier remotely.

Before You Start

Ask our technique supports or sales and purchase the keyfob.

Steps

 **Note**

- If the device is equipped with access control board, you can pair keyfob via DIP switch on the access control board only.
 - For details about button's operation, see *Configuration via Button* .
 - For details about the configuration No. and its related function, see *Button Configuration Description* .
 - For details about the keyfob operation instructions, see the keyfob's user manual.
-

1. Enter the keyfob pairing mode.
 - 1) Enter the configuration mode.
 - 2) Set the configuration No. in Level-1 to **2**. The device will enter the keyfob pairing mode.
 - 3) Set the configuration No. in the Level-2 menu to **2**. The device will enter the keyfob pairing mode.
2. Hold the **Close** button for more than 10 seconds.

The keyfob's indicator will flash if the pairing is completed.

3. Exit the keyfob pairing mode.
 - 1) Enter the configuration mode.
 - 2) Set the configuration No. in Level-1 to **2**. The device will enter the keyfob pairing mode.
 - 3) Set the configuration No. in the Level-2 menu to **1**. The device will exit the keyfob pairing mode.
4. Reboot the device to take effect.

Pair Keyfob via DIP Switch (Optional)

Pair the remote control to the device through DIP switch to open/close the barrier remotely.

Before You Start

Ask our technique supports or sales and purchase the keyfob.

Steps

1. Power off the turnstile.
2. Set the No.2 switch of the DIP Switch on the access control board to the ON side.




Figure 6-25 DIP Switch Location




Figure 6-26 Enable Keyfob Pairing Mode

3. Power on the turnstile and it will enter the keyfob pairing mode.
4. Hold the **Close** button for more than 10 seconds.
The keyfob's indicator will flash twice if the pairing is completed.
5. Set the No.2 switch to the OFF side, and reboot the turnstile to take effect.

Note

- Only one turnstile can pair the keyfob. If multiple turnstiles are in the pairing mode, the keyfob will select only one of them to pair.
 - For details about DIP switch value and meaning, see [DIP Switch Description](#).
6. **Optional:** Go to **System → User → Keyfob User** on the remote control page of the client software to delete the keyfob.

6.4.4 Initialize Device

Steps

1. Hold the initialization button on the access control board for 5 s.




Figure 6-27 Initialization Button Position

2. The device will start restoring to factory settings.
3. When the process is finished, the device will beep for 3 s.

Caution

The initialization of the device will restore all the parameters to the default setting and all the device events are deleted.

Note

Make sure no persons are in the lane when powering on the device.

Chapter 7 Activation

You should activate the device before the first login. After powering on the device, the system will switch to Device Activation page.

Activation via the device, SADP tool and the client software are supported.

The default values of the device are as follows:

- The default IP address: 192.0.0.64
- The default port No.: 80
- The default user name: admin

7.1 Activate via Web Browser

You can activate the device via the web browser.

Steps

1. Enter the device default IP address (192.0.0.64) in the address bar of the web browser, and press **Enter**.



Make sure the device IP address and the computer's should be in the same IP segment.

2. Create a new password (admin password) and confirm the password.



STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.



Characters containing admin and nimda are not supported to be set as activation password.

3. Click **Activate**.
4. Edit the device IP address. You can edit the IP address via the SADP tool, the device, and the client software.

7.2 Activate via Mobile Web

You can activate the device via mobile web.

Steps

1. Connect to the device hotspot with your mobile phone by entering the hotspot password.
-

Note

- For inactive devices, hotspot is enabled by default.
 - The default hotspot password is the device serial number.
-

The login page will pop up.

2. Create a new password (admin password) and confirm the password.
-

Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Note

Characters containing admin and nimda are not supported to be set as activation password.

3. Click **Activate**.
4. Edit the device IP address. You can edit the IP address via the SADP tool, the device, and the client software.

7.3 Activate via SADP

SADP is a tool to detect, activate and modify the IP address of the device over the LAN.

Before You Start

- Get the SADP software from the supplied disk or the official website <http://www.hikvision.com/en/>, and install the SADP according to the prompts.
- The device and the PC that runs the SADP tool should be within the same subnet.

The following steps show how to activate a device and modify its IP address. For batch activation and IP addresses modification, refer to *User Manual of SADP* for details.

Steps

1. Run the SADP software and search the online devices.
2. Find and select your device in online device list.
3. Input new password (admin password) and confirm the password.


Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Note

Characters containing admin and nimda are not supported to be set as activation password.

4. Click **Activate** to start activation.



The screenshot shows the SADP software interface. On the left, a table lists devices with columns for ID, Device Type, Security, IP4 Address, Port, Software Version, IP4 Gateway, HTTP Port, and Device Serial No. Device 007 is highlighted in red and labeled "Inactive" with the IP address 192.0.0.64. A red box around it contains the text "Select inactive device." Below the table, another red box contains the text "Input and confirm password." On the right, a dialog box titled "Activate the Device" shows a padlock icon and the message "The device is not activated." Below this, there is a section for "New Password" and "Confirm Password" with a strength indicator, and an "Activate" button.

Status of the device becomes **Active** after successful activation.

5. Modify IP address of the device.

- 1) Select the device.
- 2) Change the device IP address to the same subnet as your computer by either modifying the IP address manually or checking **Enable DHCP**.
- 3) Input the admin password and click **Modify** to activate your IP address modification.


7.4 Activate Device via iVMS-4200 Client Software

For some devices, you are required to create the password to activate them before they can be added to the iVMS-4200 software and work properly.

Steps

Note

This function should be supported by the device.

1. Enter the Device Management page.
 2. Click  on the right of **Device Management** and select **Device**.
 3. Click **Online Device** to show the online device area.
The searched online devices are displayed in the list.
 4. Check the device status (shown on **Security Level** column) and select an inactive device.
 5. Click **Activate** to open the Activation dialog.
 6. Create a password in the password field, and confirm the password.
-

Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

Note

Characters containing admin and nimda are not supported to be set as activation password.

7. Click **OK** to activate the device.

Chapter 8 Operation via Web Browser

8.1 Login

You can login via the web browser or the remote configuration of the client software.

Note


Make sure the device is activated.

Login via Web Browser

Enter the device IP address in the address bar of the web browser and press **Enter** to enter the login page.

Enter the device user name and the password. Click **Login**.

Login via Remote Configuration of Client Software

Download and open the client software. After adding the device, click  to enter the Configuration page.

8.2 Overview

You can view the device component status, real-time event, person information, network status, basic information, and device capacity. You can also control the barrier remotely.




Figure 8-1 Overview

Function Descriptions:

Device Component Status

You can check if the device is working properly. Click **View More** to view the detailed component status.

Remote Control

 /  /  / 

The door is opened/closed/remaining open/remaining closed.

Real-Time Event

You can view the event Employee ID, Name, Card No., Event Type, Time, and Operation. You can also click **View More** to enter the search conditions, including the event type, employee ID, the name, the card No., the start time, and the end time, and click **Search**. The results will be displayed on the right panel.

Person Information

You can view the added and not added information of person and card.

Network Status

You can view the network connection status.

Basic Information

You can view the model, serial No. and firmware version.

Device Capacity

You can view the person, card and event capacity.

8.3 Person Management

Click **Add** to add the person's information, including the basic information, certificate, authentication and settings.

Basic Information

*Employee ID

Name

Gender Male Female Unknown

Person Type Normal User Visitor Person in Blocklist

Long-Term Effective User

Validity Period -

Administrator

Certificate Configuration

Card ⓘ Up to 50 cards can be supported.

Authentication Settings

Authentication Type Same as Device Custom

Figure 8-2 Add Person

Add Basic Information

Click **Person Management** → **Add** to enter the Add Person page.

Add the person's basic information, including the employee ID, the person's name, and person type.

If you select **Visitor** as the person type, you can set the visit times.

Click **Save** to save the settings.

Set Permission Time

Click **Person Management** → **Add** to enter the Add Person page.

Enable **Long-Term Effective User**, or set **Validity Period** and the person can only has the permission within the configured time period according to your actual needs.
Click **Save** to save the settings.

Add Card

Click **Person Management** → **Add** to enter the Add Person page.
Click **Add Card**, enter the **Card No.** and select the **Property**, and click **OK** to add the card.



Up to 50 cards can be added.

Click **Save** to save the settings.

Authentication Settings

Click **Person Management** → **Add** to enter the Add Person page.
Set **Authentication Type** as **Same as Device** or **Custom**.
Click **Save** to save the settings.

Import/Export Person Data

Export Person Data

You can export added person data for back-up or importing to other devices.
Click **Export Person Data**, set an encryption password and confirm it. Click **OK**.



- The person data will be downloaded to your PC.
 - The password you set will be required for importing the data file.
-

Importing Person Data

Click **Importing Person Data** and select the file. Click **Import**.
Enter the encryption password to import and synchronize the person data to devices.

8.4 Search Event

Click **Event Search** to enter the Search page.

Event Types
Access Control Event

Employee ID

Name

Card No.

Start Time
2022-02-28 00:00:00

End Time
2022-02-28 23:59:59

Figure 8-3 Search Event

Enter the search conditions, including the event type, the employee ID, the name, the card No., the start time, and the end time, and click **Search**.

The event types contain access control event and ID card event. If you choose to search for ID card event, you will not need to enter the employee ID, the name, or the card No.

The results will be displayed on the right panel.

8.5 Configuration

8.5.1 View Device Information

Click **Configuration** → **System** → **System Settings** → **Basic Information** to enter the configuration page.

You can view the device name, language, model, serial No., version, IO input, IO output, and local RS-485 number.

You can change **Device Name** and click **Save**.

You can view the device capacity, including person, card and event.

8.5.2 Set Time

Set the device's time.

Click **Configuration** → **System** → **System Settings** → **Time Settings** .

Device Time 2015-01-01 00:37:18

Time Zone (GMT+08:00) Beijing, Urumqi, Singapore, Perth

Time Synchronization mode NTP Manual

Set Time 2015-01-01 00:36:49

DST

DST

Start Time April First Sunday 02

End Time October Last Sunday 02

DST Bias 30minute(s)

Figure 8-4 Time Settings

Click **Save** to save the settings after the configuration.

Time Zone

Select the device located time zone from the drop-down list.

Time Sync.

NTP

You should set the NTP server's IP address, port No., and interval.

Manual

By default, the device time should be synchronized manually. You can set the device time manually or check **Sync. with Computer Time** to synchronize the device time with the computer's time.

Server Address Type/Server Address/NTP Port/Interval

You can set the server address type, server address, NTP port, and interval.


8.5.3 Set DST

Steps

1. Click **Configuration** → **System** → **System Settings** → **Time Settings** .
2. Enable **DST**.
3. Set the DST start time, end time and bias time.
4. Click **Save** to save the settings.

8.5.4 Change Administrator's Password

Steps

1. Click **Configuration** → **User Management** .
2. Click  .
3. Enter the old password and create a new password.
4. Confirm the new password.
5. Click **OK**.



Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.

8.5.5 Online Users

The information of users logging into the device is shown.

Go to **Configuration** → **System** → **User Management** → **Online Users** to view the list of online users.

8.5.6 View Device Arming/Disarming Information

View device arming type and arming IP address.

Go to **Configuration** → **User Management** → **Arming/Disarming Information** .

You can view the device arming/disarming information. Click **Refresh** to refresh the page.

8.5.7 Network Settings

Set TCP/IP, hotspot and HTTP(S) parameters.

Set Basic Network Parameters

Click **Configuration** → **Network** → **Network Settings** → **TCP/IP** .

The screenshot shows the TCP/IP Settings page. At the top, there is a dropdown menu for 'NIC Type' with 'Self-Adaptive' selected. Below it is a 'DHCP' toggle switch, which is currently turned off. There are five input fields: '*IPv4 Address', '*IPv4 Subnet Mask', '*IPv4 Default Gateway', 'Mac Address', and 'MTU'. Below these is a section titled 'DNS Server' with two input fields: 'Preferred DNS Server' and 'Alternate DNS Server'. At the bottom of the form is a red 'Save' button.

Figure 8-5 TCP/IP Settings Page

Set the parameters and click **Save** to save the settings.

NIC Type

Select a NIC type from the drop-down list. By default, it is **Auto**.

DHCP

If you uncheck the function, you should set the IPv4 address, IPv4 subnet mask, IPv4 default gateway, Mac address, and MTU.

If you check the function, the system will allocate the IPv4 address, IPv4 subnet mask, the IPv4 default gateway automatically.

DNS Server

Set the preferred DNS server and the Alternate DNS server according to your actual need.

Device Hotspot

Set the device hotspot.

Click **Configuration** → **Network** → **Network Settings** → **Device Hotspot** .

Click to **Enable Device Hotspot**. Set hotspot **Name** and **Password**.

Click **Save**.

Set Port Parameters

Set the HTTP, HTTPS, and HTTP Listening parameters.

Click **Configuration** → **Network** → **Network Service** → **HTTP(S)** .

HTTP

Enable

Enabling HTTP may cause security problems.

HTTP Port

HTTPS

Enable

HTTPS Port

HTTP Listening

*Event Alarm IP Address/Domain ...

*URL

Port

Protocol HTTP

Figure 8-6 Network Service

HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter **http://192.0.0.65:81** in the browser for login.

HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

HTTP Listening

The device can send alarm information to the event alarm IP address or domain name via HTTP protocol/HTTPS protocol. Edit the event alarm IP address or domain name, URL, port, and protocol.

 **Note**

The event alarm IP address or domain name should support the HTTP protocol/HTTPS protocol to receive the alarm information.

8.5.8 Set Audio Parameters

Set the image quality, resolution, and the device volume.

Set Audio Parameters

Click **Configuration** → **Video/Audio** → **Audio** .



Figure 8-7 Set Audio Parameters

Drag the block to adjust the output volume.

Click **Save** to save the settings after the configuration.

You can also enable **Voice Prompt**.



Note

The functions vary according to different models. Refers to the actual device for details.

8.5.9 Event Linkage

Set linked actions for events.

Steps

1. Click **Configuration** → **Event** → **Event Detection** → **Linkage Settings** to enter the page.

Event Source

Linkage Type Event Linkage Card Linkage Link Employee ID

Event Types

Linkage Action

Buzzer Linkage

Start Buzzing Stop Buzzing

Door Linkage

Entrance Exit

Linked Alarm Output

Alarm Output1 Alarm Output2

Linkage Audio Prompt

Voice Prompt Type TTS Audio File

Play Mode Disable Play Once Loop

Language Chinese, Simplified English

*Prompt

Figure 8-8 Event Linkage

2. Set event source.

- If you choose **Linkage Type** as **Event Linkage**, you need to select event types from the drop-down list.
- If you choose **Linkage Type** as **Card Linkage**, you need to enter the card No. and select the card reader.

- If you choose **Linkage Type** as **Employee ID Linkage**, you need to enter the employee ID and select the card reader.

3. Set linked action.

Linked Buzzer

Enable **Linked Buzzer** and select **Start Buzzing** or **Stop Buzzing** for the target event.

Linked Door

Enable **Linked Door**, check **Entrance** or **Exit**, and set the door status for the target event.

Linked Alarm Output

Enable **Linked Alarm Output**, check **Alarm Output 1** or **Alarm Output 2**, and set the alarm output status for the target event.

Linked Audio Prompt

Enable **Linked Audio Prompt** and select the play mode.

- If you choose **TTS**, you need to set language and enter the prompt content.
- If you choose **Audio File**, you need to select an available audio file from the drop-down list or click **General Linkage Settings** to add a new audio file.

8.5.10 Access Control Settings

Set Authentication Parameters

Click **Configuration** → **Access Control** → **Authentication Settings** .



Note

The functions vary according to different models. Refers to the actual device for details.

The screenshot displays a configuration interface for a terminal. At the top, there are two buttons: 'Entrance' (highlighted with a red border) and 'Exit'. Below these are three read-only fields: 'Terminal Type' set to 'Card', and 'Terminal Model' set to '485Offline'. The 'Enable Authentication Device' is a green toggle switch that is turned on. The 'Authentication' field is a dropdown menu currently showing 'Card'. The 'Authentication Interval' is a numeric input field set to '0'. The 'Alarm of Max. Failed Attempts' is a grey toggle switch that is turned off. The 'Communication with Controller Every' is another numeric input field set to '0'. At the bottom center, there is a red 'Save' button.

Figure 8-9 Set Authentication Parameters

Click **Save** to save the settings after the configuration.

Terminal

Choose **Entrance** or **Exit** for settings.

Terminal Type/Terminal Model

Get terminal description. They are read-only.

Enable Authentication Device

Enable the authentication function.

Authentication

Select an authentication mode according to your actual needs from the drop-down list.

Authentication Interval

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed.

Alarm of Max. Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Max. Authentication Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Communication with Controller Every


When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.

Note

The authentication interval value ranges from 2 s to 255 s.

Set Door Parameters

Click **Configuration** → **Access Control** → **Door Parameters** .



The screenshot shows the 'Door Parameters Settings Page' with the following fields and options:

- Door No.:** Two buttons, 'Entrance' (highlighted in red) and 'Exit'.
- Door Name:** A text input field.
- Open Duration:** A text input field containing '8', with a 's' unit and up/down arrows.
- Exit Button Type:** Two radio buttons: 'Remain Closed' (unselected) and 'Remain Open' (selected).
- Door Remain Open Duration with ...:** A text input field containing '10', with a 'min' unit and up/down arrows.
- Save:** A red button at the bottom.

Figure 8-10 Door Parameters Settings Page

Click **Save** to save the settings after the configuration.

Door No.

Select **Entrance** or **Exit** for settings.

Door Name

You can create a name for the door.

Open Duration

Set the door unlocking duration. If the door is not opened for the set time, the door will be locked.

Note

The open duration ranges from 5 s to 60 s.

Exit Button Type

You can set the exit button as **Remain Open** or **Remain Closed** according to your actual needs. By default, it is **Remain Open**.

Door Remain Open Duration with First Person

Set the door open duration when first person is in. After the first person is authorized, it allows multiple persons access the door or other authentication actions.

Note


The duration ranges from 1 s to 1440 s.

Serial Port Settings

Set serial port parameters.

Steps

1. Click **Configuration** → **Access Control** → **Serial Port Configuration** .



Serial Port Type RS232

No. 1

Baud Rate 19200

Data Bit 8

Stop Bit 1 2

Parity None Odd Parity Even Verification

Peripheral Type Card Reader Card Receiver QR Code Scanner Disable

External Device Model None

Peripheral Software Version None

Save

Figure 8-11 Serial Port Settings

2. Set the **No.**, **Baud Rate**, **Data Bit**, **Stop Bit** and **Parity**.
3. Set the **Peripheral Type** as **Card Reader**, **QR Code Scanner** or **Disable**.
4. You can view the serial port type, connected device model and peripheral software version.
5. Click **Save**.

Set Wiegand Parameters

You can set the Wiegand transmission direction.

Steps

Note

Some device models do not support this function. Refer to the actual products when configuration.

1. Click **Configuration** → **Access Control** → **Wiegand Settings** .
 2. Select **Entrance** or **Exit**.
 3. Enable **Wiegand** function.
 4. The wiegand transmission direction is set **Input** by default.
-

Note

Input: the device can connect a Wiegand card reader.

5. Click **Save** to save the settings.
-

Note

If you change the peripheral, and after you save the device parameters, the device will reboot automatically.

Host Parameters

Set door contact settings and RS-485 protocol.

Steps

1. Click **Configuration** → **Access Control** → **Host Parameter** to enter the page.
 2. Set door contact.
-

Note

You can set the door contact as **Door Open Status** or **Door Closed Status** according to your actual needs. By default, it is **Door Open Status**.

3. Set RS-485 protocol.
 4. Click **Save**.
-

Set Terminal Parameters

Set the working mode and remote verification.

Steps

1. Click **Configuration** → **Access Control** → **Terminal Parameters** to enter the page.




Figure 8-12 Terminal Parameters

2. Set the device working mode.

Permission Free Mode

The device will not verify the person's permission, but only the person's validity period. If the person is in the validity period, the barrier will open.

You can enable **Verify Credential Locally**. After enabling the function, the device will only verify the person's permission without the schedule template, etc.

Access Control Mode

The device works normally and will verify the person's permission to open the barrier.

3. Set remote verification.

- 1) Enable **Remote Verification**.

Note

The device will upload the person's authentication information to the platform. The platform will judge to open the barrier or not.

- 2) **Optional:** Enable **Verify Credential Locally**.

Note

After enabling the function, the device will only verify the person's permission without the schedule template, etc.

4. Click **Save** to complete terminal parameter settings.

8.5.11 Turnstile

Basic Parameters

Set turnstile basic parameters.

Steps

1. Click **Configuration** → **Turnstile** → **Basic Settings** to enter the page.
2. View the **Device Type**, **Device Model** and **Working Status**.
3. Set **Barrier Material**, **Lane Width**, **Barrier Height**, **Barrier Opening Speed** and **Barrier Closing Speed**.
4. Set the passing mode.
 - If you choose **General Passing**, you can select the barrier status for the entrance and exit from the drop-down list.



Note

If you set barrier-free mode, the barrier remains open and will close when authentication fails.

- If you choose **Weekly Schedule**, you can set a weekly schedule for entrance and exit barriers.
5. Click **Save**.

keyfob

Set keyfob parameters.

Steps

1. Click **Configuration** → **Turnstile** → **Keyfob** to enter the page.




Figure 8-13 keyfob

2. Set **Working Mode** as **One-to-One** or **One-to-Many**.
3. Add keyfob.
 - 1) Click **Add** and the keyfob adding window will pop up.
 - 2) Enter the **Name** and **Serial No.**
 - 3) Check to enable **Remain Open Permission** at your actual needs.
 - 4) Click **OK** to add the keyfob.

4. **Optional:** Select a keyfob and click **Delete** to delete the keyfob.
5. Click **Save**.

IR Detector

Set IR detector.

Steps

1. Click **Configuration** → **Turnstile** → **IR Detector** to enter the page.




Figure 8-14 IR Detector

2. Set the entrance and exit inductive mode as **Single Triggered** or **Triggered Simultaneously**.
3. Set custom IR detector mode.

Enable IR Emergency Mode

If some IR beams do not work properly, you can shield those IR beams to restore the lane. But this action may hit person and cause injury.

Enable Custom Anti-pinch for Door Closing

Anti-pinch for door closing refers that the barrier will not close if the device has detected person in the lane. Only after the person walks out of the lane, the barrier will close. If you enable the function, you can shield parts of the IR beams for closing barrier in advance. But this action may hit person and cause injury.

4. Click **Save**.

People Counting

Set people counting .

Steps

1. Click **Configuration** → **Turnstile** → **People Counting** to enter the page.



Figure 8-15 People Counting

2. Check to enable **People Counting**.
3. Enable **Device Offline People Counting** at your actual needs.
4. Select **People Counting Type** as **Invalid**, **Passing Detection** or **Authentication Number**.
5. **Optional:** Click **clear** to clear all the people counting information.

Set Indicator Color

Set the color for the indicators.

Steps

1. Click **Configuration** → **Turnstile** → **Light Settings** to enter the page.
2. Set light color for lane status indicator.
 - 1) Set **Light Brightness** as **Auto** or **Fixed Brightness**. If you choose **Fixed Brightness**, you can drag the block or enter the value to adjust the light brightness manually.
 - 2) Set inductive, prohibited and Auth. passing light color.
3. Set barrier light color.
 - 1) Check to enable **Light on When on Standby** at your actual needs.
 - 2) Set the barrier light color.
4. Click **Save**.

Other Settings

Set other parameters.

Steps

1. Click **Configuration** → **Turnstile** → **Other Settings** to enter the page.
2. Set **Alarm Output Duration**.

Note

The alarm output duration ranges from 0 s to 3599 s.

3. Set **Temperature Unit**.
 4. Check to enable **Do Not Open Barrier When Lane is Not Clear**.
 5. Drag the block or enter the value to adjust the light board brightness.
 6. Set the alarm buzzer beeping duration, door closing delay time, intrusion duration, overstaying duration and IR obstructed duration.
 7. Check to enable **Memory Mode** at your actual needs.
-

Note

Multiple cards presenting for multiple person passing is allowable when enabling the memory mode. When the passing person's number exceeds the card presenting number, or after the latest person passing with no other person passing within the door open duration, the door will close automatically.

8. Choose the control mode.

Soft Mode

The barrier will be closed after the person has passed through the barrier when there are tailing, forced accessing, etc.

Guard Mode

The barrier will be closed immediately when there are tailgating, forced accessing, etc.

9. Click to enable **Motor Self-Test** and choose the main lane or sub lane to start motor self-testing.
10. Click **Save**.

8.5.12 Card Settings

Set Card Security

Click **Configuration** → **Card Settings** → **Card Type** to enter the settings page.

Set the parameters and click **Save**.

Enable NFC Card

In order to prevent the mobile phone from getting the data of the access control, you can enable NFC card to increase the security level of the data.

Enable M1 Card

Enable M1 card and authenticating by presenting M1 card is available.

M1 Card Encryption

Sector

M1 card encryption can improve the security level of authentication.

Enable the function and set the encryption sector. By default, Sector 13 is encrypted. It is recommended to encrypt sector 13.

Enable EM Card

Enable EM card and authenticating by presenting EM card is available.



Note

If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function.

Enable CPU Card

Enable CPU card and authenticating by presenting CPU card is available.

CPU Card Read Content

After enable the CPU card content reading function, the device can read the CPU card content.

Enable FeliCa Card

The device can read the data from FeliCa card when enabling the FeliCa card function.

Set Card Authentication Parameters

Set the card reading content when authenticate via card on the device.

Go to **Configuration** → **Card Settings** → **Card NO. Authentication Settings** .

Select a card authentication mode and enable reversed card No. at your actual needs. Click **Save**.

8.5.13 Set Privacy Parameters

Set the event storage type.

Go to **Configuration** → **Security** → **Privacy Settings**

The event storage type is overwriting by default. The earliest 5% events will be deleted when the system detects the stored events has been over 95% of the full space.

8.5.14 Prompt Schedule

Customize the output audio content when authentication succeeded and failed.

Steps

1. Click **Configuration** → **Preference** → **Prompt Schedule** .

Enable

Appellation Name Family Name None

Time Period When Authentication Succeeded

Period1

Time

Voice Prompt Type TTS Audio File

* Audio Prompt Content

[+ Add Time Duration](#)

Time Period When Authentication Failed

Period1

Time

Voice Prompt Type TTS Audio File

* Audio Prompt Content

[+ Add Time Duration](#)

Figure 8-16 Customize Audio Content

2. Select time schedule.
3. Enable the function.
4. Set the appellation.
5. Set the time period when authentication succeeded.
 - 1) Click **Add Time Duration**.
 - 2) Set the time duration.

Note

If authentication is succeeded in the configured time duration, the device will broadcast the configured content.

-
- 3) Set the audio content.

TTS


If you choose TTS, you need to set the language and enter the prompt content of authentication success.

Audio File

If you choose audio file, you need to select an available audio file from the drop-down list or click **Audio File Management** to add a new file.

Note

The audio file's format should be wav, and the size should be within 200 KB.

-
- 4) **Optional:** Repeat substep 1 to 3.
 - 5) **Optional:** Click  to delete the configured time duration.
6. Set the time duration when authentication failed.
 - 1) Click **Add**.
 - 2) Set the time duration.

Note

If authentication is failed in the configured time duration, the device will broadcast the configured content.

-
- 3) Set the audio content.

TTS


If you choose TTS, you need to set the language and enter the prompt content of authentication failure.

Audio File

If you choose audio file, you need to select an available audio file from the drop-down list or click **Audio File Management** to add a new file.

Note

The audio file's format should be wav, and the size should be within 200 KB.

-
- 4) **Optional:** Repeat substep 1 to 3.
 - 5) **Optional:** Click  to delete the configured time duration.
7. Click **Save** to save the settings.


8.5.15 Upgrade and Maintenance

Reboot device, restore device parameters, and upgrade device version.

Reboot Device

Click **Maintenance and Security** → **Maintenance** → **Restart** .
Click **Restart** to reboot the device.

Upgrade

Click **Maintenance and Security** → **Maintenance** → **Upgrade** .
Select an upgrade type from the drop-down list. Click  and select the upgrade file from your local PC. Click **Upgrade** to start upgrading.

Note

Do not power off during the upgrading.

Restore Parameters

Click **Maintenance and Security** → **Maintenance** → **Backup and Reset** .

Restore All

All parameters will be restored to the factory settings. You should activate the device before usage.

Restore

The device will restore to the default settings, except for the network parameters and the user information.

Import and Export Parameters

Click **Maintenance and Security** → **Maintenance** → **Backup and Reset** .

Export

Click **Export** to export the device parameters.

Note

You can import the exported device parameters to another device.

Import

Click  and select the file to import. Click **Import** to start import configuration file.

8.5.16 Device Debugging

You can set device debugging parameters.

Steps

1. Click **Maintenance and Security** → **Maintenance** → **Device Debugging** .
2. You can set the following parameters.

Enable SSH

To raise network security, disable SSH service. The configuration is only used to debug the device for the professionals.

Print Log

You can click **Export** to export log.

8.5.17 Component Status

You can view the main lane and sub lane status.

Main Lane Status

Device Component

You can view the status of the access control board, lane control board, user extended interface board, and passing mode indicator board.

Peripheral

You can view the status of the RS-485 card reader and tamper input.

Temperature

You can view the pedestal temperature.

Movement

You can view the working status of motor encoder.

Sub Lane Status

Device Component

You can view the status of the lane control board, passing mode indicator board and upper IR adaptor.

Peripheral

You can view the status of the RS-485 card reader, RS-232 card receiver and tamper input.

Movement

You can view the working status of motor encoder.

Others

Passing Mode

You can view the entrance and exit mode.

IR Detector Status

You can view the status of each pair of the IR beam sensors.

Input and Output Status

You can view the status of the event input/output, alarm input/output and fire alarm.

Other Status

You can view the status of the barrier and the keyfob receiving module.

8.5.18 Log Query

You can search and view the device logs.

Go to **Maintenance and Security** → **Maintenance** → **Log** .

Set the major and minor type of the log type. Set the start time and end time for searching, and click **Search**.

The results will be displayed below, which including the No., time, the major type the minor type, the channel No., the local/remote user information, the remote host IP, etc.

8.5.19 Certificate Management

It helps to manage the server/client certificates and CA certificate.



Note

The function is only supported by certain device models.

Create and Install Self-signed Certificate

Steps

1. Go to **Maintenance and Security** → **Security** → **Certificate Management** .
2. In the **Certificate Files** area, select a **Certificate Type** from the drop-down list.
3. Click **Create**.
4. Input certificate information.
5. Click **OK** to save and install the certificate.

The created certificate is displayed in the **Certificate Details** area.

The certificate will be saved automatically.

6. Download the certificate and save it to an asking file in the local computer.
7. Send the asking file to a certification authority for signature.
8. Import the signed certificate.
 - 1) Select a certificate type in the **Import Passwords** area, and select a certificate from the local, and click **Install**.
 - 2) Select a certificate type in the **Import Communication Certificate** area, and select a certificate from the local, and click **Install**.

Install Other Authorized Certificate

If you already has an authorized certificate (not created by the device), you can import it to the device directly.

Steps

1. Go to **Maintenance and Security → Security → Certificate Management** .
2. In the **Import Passwords** and **Import Communication Certificate** areas, select certificate type and upload certificate.
3. Click **Install**.

Install CA Certificate

Before You Start

Prepare a CA certificate in advance.

Steps

1. Go to **Maintenance and Security → Security → Certificate Management** .
2. Create an ID in the **Import CA Certificate** area.



Note

The input certificate ID cannot be the same as the existing ones.

3. Upload a certificate file from the local.
4. Click **Install**.

Chapter 9 Configure the Device via the Mobile Web

9.1 Login

You can login via mobile browser.

 **Note**

Make sure the device is activated.

Enter the device IP address in the address bar of the mobile browser and press **Enter** to enter the login page.

Enter the device user name and the password. Click **Login**.

9.2 Overview

You can view the device status, conduct remote control, etc.




Figure 9-1 Status and Quick Settings

You can view the device status. If there is exception, you can tap to view the component details. You can tap to fast enter the basic settings page, user page, keyfob page and network page batch device management page.




Figure 9-2 Remote Control

You can remotely control barrier by tap the icons.





Figure 9-3 Network Status and Basic Information

You can view network status, model, serial No. and firmware version, and you can tap to fast enter the basic information page.

9.3 Configuration

9.3.1 Turnstile Basic Settings

You can set the basic parameters of the turnstile.

Tap **Basic Settings** of the shortcut entry on the overview page or tap  → **Basic Settings** .




Figure 9-4 Turnstile Basic Parameters

Set **Lane Width**, **Barrier Material**, **Opening Barrier Speed** and **Closing Barrier Speed**.

Tap **Regular Passing Settings** to set the entrance and exit's passing mode.

Tap **Lane Width Diagram** to view the device diagram.

Tap **Save**.

9.3.2 Person Management

You can add, edit, delete, and search person via mobile Web browser.

Steps

1. Tap **User** of the shortcut entry or tap  → **Person Management** to enter the settings page.

The screenshot shows a mobile application interface for adding a person. At the top, there is a navigation bar with a back arrow on the left, the title 'Add Person' in the center, and a 'Save' button on the right. Below the navigation bar is a form with several input fields and a toggle switch. The fields are: '*Employee ID' with the placeholder text 'Please enter.', 'Name' with the placeholder text 'Please enter.', 'Long-Term Effective User' with a toggle switch that is currently turned off, 'Start Date' with the value '2024-01-23 00:00:00' and a right-pointing arrow, 'End Date' with the value '2034-01-22 23:59:59' and a right-pointing arrow, 'User Role' with the value 'Normal User' and a right-pointing arrow, and 'Card' with the value 'Not added.' and a right-pointing arrow.

Figure 9-5 Add Person

2. Add person.

- 1) Tap+.
- 2) Set the following parameters.

Employee ID

Enter the employee ID. The Employee ID cannot be 0 or exceed 32 characters. It can be a combination of uppercase, lowercase letters and numbers.

Name

Enter your name. The name supports numbers, uppercase and lowercase English, and characters. The name is recommended to be within 32 characters.

Long-Term Effective User

Set the user permission as long-term effective.

Start Date/End Date

Set **Start Date** and **End Date** of user permission.

User Role

Select your user role.

Card

Add card. Tap **+**. Enter the **Card No.**, and select the **Card Type**. Tap **Save** to add the card.

3) Tap **Save**.

3. Tap the user that needs to be edited in the user list to edit the information.

4. You can search the user by entering the employee ID in the search bar.

9.3.3 Keyfob Settings

Tap **Keyfob** of the shortcut entry on the overview page.




Figure 9-6 Keyfob Settings

Set **Working Mode** as **One-to-One** or **One-to-Many**.

Tap **Management** to enter the page. Tap + to add keyfob. Set keyfob name, serial No. and remain open permission.

9.3.4 Light Settings

Tap **Light** of the shortcut entry on the overview page.

Side Light




Figure 9-7 Side Light Settings

Set **Light Brightness** as **Auto** or **Fixed Brightness**. If you choose **Fixed Brightness**, you can enter the value to adjust the light brightness manually.

Set inductive, prohibited and Auth. passing light color.

Barrier Light




Figure 9-8 Barrier Light Settings

Tap to enable **Light on When on Standby** at your actual needs and set the barrier light color.

9.3.5 View Device Basic Information

You can view the device name, language, model, serial No., version, and Mac address, etc.

Tap  → **System Settings** → **Basic Information** .

You can change the device name.

You can view the device language, model, serial No., version, local RS-485 number, number of alarm input, number of alarm output, Mac address and factory information, etc.

Tap **Device Capacity** to view the quantity and capacity of person, card and event.

Tap **Save**.

9.3.6 Time Settings

View current time and set the time zone.

Tap  → **System Settings** → **Time Settings** .




Figure 9-9 Time Settings

Device Time

You can view current time.

Time Zone

Select the time zone where the device is located from the drop-down list.

Time Sync. Mode

Manual

By default, the device time should be synchronized manually. You can set the device time manually.

NTP

Set the NTP server's IP address, port No., and interval.

DST

Slide to enable DST, and set the start time, end time and DST bias.

Tap **Save**.

9.3.7 User Management

You can change user password.

Tap  → **User Management** on the home page.

Tap the user, enter the old password and create a new password, and confirm the password.

Tap **Save**.

9.3.8 Network

Wired Network

Set wired network.

Tap  → **Network Settings** → **Wired Network** to enter the configuration page.

NIC Type

Select a NIC type from the drop-down list.

DHCP

If you disable the function, you should set the IPv4 address, subnet mask, gateway.

If you enable the function, the system will allocate the IPv4 address, subnet mask, gateway automatically.

MAC Address and MTU

You can view the default MAC address and MTU.

IPv6 Mode

Route Advertisement

The IPv6 address is generated by combining the route advertisement and the device Mac address.

Note

Route advertisement mode requires the support from the router that the device is connected to.

Manual

Enter **IPv6 Address**, **IPv6 Subnet Prefix Mask**, and **IPv6 Default Gateway**. Consult the network administrator for required information.

DHCP

The IPv6 address is assigned by the server, router, or gateway.

DNS Server

Note

Only when DHCP is enabled can DNS server be set.

Set the preferred DNS server and the alternate DNS server according to your actual need.

Set Port Parameters

You can set the HTTP, HTTPS according to actual needs when accessing the device via network.

Tap  → **Network Service** → **HTTP(S)** to enter the setting page.

HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter ***http://192.0.0.65:81*** in the browser for login.

HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

Device Hotspot

Set device hotspot.

Tap  → **Configuration** → **Network Settings** → **Device Hotspot** to enter the configuration page.




Figure 9-10 Device Hotspot

Tap to **Enable Device Hotspot**. Set hotspot **Name** and **Password**.
Click **Save**.

Platform Access

Platform access provides you an option to manage the devices via platform.

Steps

1. Tap  → **Device Access** → **Hik-Connect** to enter the settings page.

Note

Hik-Connect is an application for mobile devices. With the App, you can view live image of the device, receive alarm notification and so on.

2. Slide to enable the function.
3. You can enable **Custom** to enter the server address.

Note

- 6 to 12 letters (a to z, A to Z) or numbers (0 to 9), case sensitive. You are recommended to use a combination of no less than 8 letters or numbers.

4. You can view **Register Status** and **Binding Status**.
5. You can tap **Bind An Account** → **View QR Code** , scan the QR code to bind an account.
6. Tap **Save** to enable the settings.

Set OTAP Parameters

Connect the device to the platform through the OTAP protocol to obtain device information, upload operation status and alarm information, restart and upgrade the device.

Steps

1. Tap  → **Device Access** → **OTAP** .




Figure 9-11 OTAP

2. Slide to **Enable**.
3. Set server address, port, device ID and encryption key.
4. Tap **Save**.
5. Refresh the page or reboot the device, and you can view the **Register Status**. Tap **Test** to test the register status.

9.3.9 Event Search

Tap  → **Event Search** .

The screenshot shows a mobile application interface titled "Event Search". At the top left is a back arrow, and at the top right is a "Search" button. The main content area contains several search criteria fields, each with a horizontal line below it for input:

- Event Types: Access Control Event >
- Major Type: All Type >
- Sub Type: All Type >
- Employee ID
- Name
- Card No.
- Start Time: 2024-01-17 00:00:00
- End Time: 2024-01-17 23:59:59

Figure 9-12 Event Search

Select event types, major type and sub type. Enter search conditions, including employee ID, name, card No., start time and end time. Tap **Search**.

 **Note**


It supports searching for names within 128 digits.

The search results will be displayed in the list.

9.3.10 Set Audio

Set the device volume.

Steps

1. Tap  → **Audio** to enter the settings page.


2. You can adjust the device output volume according to your actual needs.
3. You can enable voice prompt according to your actual needs.

9.3.11 Access Control Settings

Set Authentication Parameters

Set authentication parameters.

Steps

1. Tap  → Access Control → Authentication Settings .




Figure 9-13 Authentication Settings

2. Tap **Save** after configuration.

Terminal

Choose **Entrance** or **Exit** for settings.

Terminal Type/Model

You can view the current terminal type and model.

Enable Authentication Device

The terminal can be used for card swiping normally when the function is enabled.

Authentication

Select an authentication mode according to your actual needs from the drop-down list.

Authentication Interval

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed. If other people authenticate in the configured interval, this person can authenticate again.



The configuration range is 0 to 255 s.

Alarm of Max. Failed Attempts

Enable **Alarm of Max. Failed Attempts** and you can set the max. authentication failed attempts. When the authentication attempts reach the set value, the authentication will be failed and report to center.



The configuration range is 1 to 10.

Communication with Controller Every

When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.

Set Door Parameters

You can set door name, open duration and exit button parameters.

Tap  → **Access Control** → **Door Parameters** .

← Door Parameters Save

Door No. Entrance >

Name

Open Duration 8

Exit Button Type Remain Open >

Door Remain Open Duration with First Person (min) 1

Figure 9-14 Door Parameters

Select entrance or exit for configuration, configure **Name** and **Open Duration**, and select **Exit Button Type**.

Configure **Door Remain Open Duration with First Person**. The mode is applicable for the passing of groups of persons, such as visitors entering the scenic spots. After the set person passes through, the door will open for a set time and other persons can pass through without authentication.

Click **Save** to save the settings after the configuration.

Terminal Settings

Set the working mode.

Tap  → **Access Control** → **Terminal Parameters** to enter the settings page.




Figure 9-15 Terminal Parameters

Permission Free Mode

The device will not verify the person's permission, but only the person's validity period. If the person is in the validity period, the barrier will open.

You can enable **Verify Credential Locally**. After enabling the function, the device will only verify the person's permission without the schedule template, etc.

Access Control Mode

The device works normally and will verify the person's permission to open the barrier.

Remote Authentication

The device will upload the person's authentication information to the platform. The platform will judge to open the barrier or not.

Verify Credential Locally

The device will only verify the person's permission without the schedule template, etc.

Set Card Security

Configure cards for the device.

Tap  → **Access Control** → **Card Security** .




Figure 9-16 Card Security

Configure card parameters, and click **Save**.

Enable NFC Card

In order to prevent the mobile phone from getting the data of the access control, you can disable NFC card to increase the security level of the data.

Enable M1 Card

Enable M1 card and authenticating by presenting M1 card is available.

M1 Card Encryption

M1 card encryption can improve the security level of authentication.

Sector

Enable the function and set the encryption sector.



It is recommended to encrypt sector 13.

Enable EM Card

Enable EM card and authenticating by presenting EM card is available.



If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function

Enable DESFire Card

The device can read the data from DESFire card when enabling the DESFire card function.

DESFire Card Read Content

After enable the DESFire card content reading function, the device can read the DESFire card content.


Enable FeliCa Card

The device can read the data from FeliCa card when enabling the FeliCa card function.

9.3.12 Upgrade and Maintenance

Restart device, restore device parameters, and upgrade device version.

Restart Device

Tap  → **Restart** .

Tap **Restart** to restart the device.

Upgrade


Tap  → **Upgrade** .

Tap **Upgrade** to upgrade the device.



Do not power off during the upgrading.

Restore Parameters

Tap  → **Default** .

Restore to Default Settings

The device will restore to the default settings, except for the device IP address and the user information.

Restore to Factory Settings

All parameters will be restored to the factory settings. You should activate the device before usage.

Log Export

Tap  → **Log Export** .

Select the log type, and tap **Export** to download the maintenance log.

9.3.13 View User Document

View the user document.



Note

Only when you enter the mobile web by IP address, can you view the user document. Login by hot spot does not support the function.

Tap  to enter the page.

Tap **View Online Document** to view the user manual.

9.3.14 View Open Source Software License on Mobile Web

Tap  → **Open Source Software Licenses** to view the device license.

9.3.15 Log Out

Log out the configuration page.

Tap  → **Logout** , tap **OK**.

If you need to enter the configuration page, you need to enter the user name and password again.

Chapter 10 Other Platforms to Configure

You can also configure the device via iVMS-4200 Client Software or HikCentral Access Control. For details, see the platforms' user manual.

iVMS-4200 Client Software

Click/tap the link to view the client software's user manual.

<http://enpinfodata.hikvision.com/analysisQR/showQR/ca930247>

Appendix A. DIP Switch

A.1 DIP Switch Description

The DIP switch is on the access control board. No.1 and No 2 is from the low bit to the high bit.




Figure A-1 DIP Switch





When the switch is towards ON, it means the switch is enabled, otherwise, the switch is off.

A.2 DIP Switch Corresponded Functions

 **Note**




After setting the DIP switch, you should reboot the device, or the function cannot take effect.

The 2-bit DIP switch corresponded functions on the access control board are as follows:



| Bit | Device Mode | Function | Decimal Value | DIP Switch Address Diagram |
|-----|--------------------|----------------------------|---------------|---|
| 1 | Work Mode | Normal Mode | 0 |  |
| | | Study Mode | 1 |  |
| 2 | Keyfob Paring Mode | Disable Keyfob Paring Mode | 0 |  |
| | | Enable Keyfob Paring Mode | 1 |  |






Appendix B. Button Configuration Description






Refer to the table below for device configuration via button on the main lane control board.






| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|---------------------|--|---|
| 1 | Study Mode | 1-Exit Study Mode/ Normal Mode 2-Study Mode  Note By default, 1 will be displayed on the display screen. | If the device is equipped with access control board, you can only set via DIP switch. |
| 2 | keyfob Pairing Mode | 1-Normal Mode 2-Pairing Mode  Note By default, 1 will be displayed on the display screen. | If the device is equipped with access control board, you can only set via DIP switch. |
| 3 | Passing Mode | 1-Both sides under control  Note By default, 1 will be displayed on the display screen. 2-Entrance under control; exit prohibited 3-Entrance under control; exit on inductive mode 4-Both sides on inductive mode | |






| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|-------------|--|-------|
| | | 5-Entrance on inductive mode; exit under control 6-Entrance on inductive mode; exit prohibited 7-Both sides prohibited 8-Entrance prohibited; exit under control 9-Entrance prohibited; exit on inductive mode 10-Entrance under control; exit remaining open 11-Entrance under control; exit on free mode 12-Entrance on inductive mode; exit remaining open 13-Entrance on inductive mode; exit on free mode 14-Entrance prohibited; exit remaining open 15-Entrance prohibited; exit on free mode 16-Entrance remaining open; exit under control 17-Entrance remaining open; exit on inductive mode | |






| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|-----------------------|--|-------|
| | | 18-Entrance remaining open; exit remaining open 19-Entrance remaining open; exit on free mode 20-Entrance remaining open; exit prohibited 21-Entrance on free mode; exit under control 22-Entrance on free mode; exit on inductive mode 23-Entrance on free mode; exit remaining open 24-Entrance on free mode; exit on free mode 25-Entrance on free mode; exit prohibited | |
| 4 | Memory Mode | 1-Disable 2-Enable  Note By default, 2 will be displayed on the display screen. | |
| 5 | keyfob Remote Control | 1-one to one 2-one to multiple  Note By default, 1 will be displayed on the display screen. | |



| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|--------------------------------|--|-------|
| 6 | Barrier Opening Speed | 1-1, 2-2, ...10-10  Note By default, 5 will be displayed on the display screen. | |
| 7 | Barrier Closing Speed | 1-1, 2-2, ...10-10  Note By default, 5 will be displayed on the display screen. | |
| 8 | Card Reading on the Alarm Area | 1-Do not open 2-Open  Note By default, 2 will be displayed on the display screen. | |
| 9 | Enter Duration | 5-5s, 6-6s, 7-7s, ..., 60-60s  Note By default, 5 will be displayed on the display screen. | |
| 10 | Exit Duration | 5-5s, 6-6s, 7-7s, ..., 60-60s  Note By default, 5 will be displayed on the display screen. | |
| 11 | IR Sensing Duration | 0-0s, 1-1s, 2-2s,..., 25-25s | |






| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|--------------------------------|---|------------------|
| | |  Note By default, 0 will be displayed on the display screen. | |
| 12 | Intrusion Duration | 0-0s, 1-1s, 2-2s,..., 20-20s  Note By default, 0 will be displayed on the display screen. | |
| 13 | Overstay Duration | 0-0s, 1-1s, 2-2s,..., 20-20s  Note By default, 0 will be displayed on the display screen. | |
| 14 | Delay Time for Barrier Closing | 0-0s, 1-1s, 2-2s, 3-3s, 4-4s, 5-5s  Note By default, 0 will be displayed on the display screen. | |
| 15 | Control Mode | 1-Button Configuration 2-DIP Switch on Access Control Board  Note By default, 1 will be displayed on the display screen. | |
| 18 | Lane Number | 1-Dual Lanes | Unable to change |


| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|-----------------------|---|---|
| | | 2-Single Lane  Note By default, 1 will be displayed on the display screen. | |
| 19 | Motor Rotation | 1-Clockwise 2-Anticlockwise  Note By default, 1 will be displayed on the display screen. | Unable to change |
| 21 | Volume | 1-0, 2-1, 3-2, 4-3, 5-4  Note By default, 2 will be displayed on the display screen. | The device will be muted when set to "1". |
| 22 | Authenticated Passing | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |
| 23 | Invalid Card No. | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |


| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|----------------------------|--|-----------------------------|
| 24 | Fingerprint Unmatched | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |
| 25 | Climbing over Barrier | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | |
| 26 | Reverse Passing | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | |
| 27 | Exceeding Passing Duration | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | |
| 28 | Intrusion Alarm | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | |

| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|-----------------------------------|--|-----------------------------|
| 29 | Forced Passing | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |
| 30 | Tailgating Alarm | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | |
| 31 | Unauthorized Passing | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |
| 32 | Exceeding Authentication Duration | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |
| 33 | Failed Authentication | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |

| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|--------------------|--|-----------------------------|
| 34 | Expired Credential | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | Unable to change via button |
| 35 | Overstaying Alarm | 1-Disable 2-Enable  Note By default, 1 will be displayed on the display screen. | |
| 36 | Barrier Material | 1-Acrylic 2-Stainless Steel 3-Glass | |
| 37 | Barrier Length | 1-550 2-600 3-650 4-700 5-750 6-800 7-850 8-900 9-950 10-1000 11-1100 12-1200 13-1300 14-1400 | |

| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|-------------------------|---|--|
| | |  Note By default, 8 will be displayed on the display screen. | |
| 38 | Motor Inspection | 1-Disable 2-Enable on Main Lane 3-Enable on Sub Lane  Note By default, 1 will be displayed on the display screen. | |
| 39 | Brightness of Light | 0-0, 1-1, 2-2, ... , 10-10  Note By default, 3 will be displayed on the display screen. | The higher the value is, the brighter the light will be. |
| 40 | Self-check Voice Prompt | 1-Disable 2-Enable  Note By default, 2 will be displayed on the display screen. | |
| 41 | Study Mode Voice Prompt | 1-Disable 2-Enable  Note By default, 2 will be displayed on the display screen. | |

| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|--------------------------|---|-----------------------------|
| 42 | c | 4-4, 6-6, 8-8,  Note By default, 4 will be displayed on the display screen. | Unable to change via button |
| 43 | Application Mode | 1-Wind-proof 2-Indoor By default, 1 will be displayed on the display screen. | |
| 44 | Barrier Recover Duration | 1-Normal Speed 2-Fast Recover By default, 1 will be displayed on the display screen. | |
| 45 | Brake | 1-Disable 2-Barrier Position Exception 3-Intrusion By default, 2 will be displayed on the display screen. | |
| 46 | Brake Angle | 1-5° 2-10° 3-15° By default, 1 will be displayed on the display screen. | |
| 47 | IR Sensing | 1-Single Triggered 2-Triggered Simultaneously | |

| Level-1 Configuration No. | Description | Level-1 Configuration No. and Functions | Notes |
|---------------------------|--------------------|---|-------|
| | | By default, 1 will be displayed on the display screen. | |
| 48 | Fan | 1-Disabled 2-Enabled By default, 2 will be displayed on the display screen. | |
| 49 | Barrier Height | 1-700 2-1200 3-1400 4-1600 5-1800 By default, 5 will be displayed on the display screen. | |
| 99 | Restore to Default | 1- Default 2- Start  Note By default, 1 will be displayed on the display screen. | |

Appendix C. Event and Alarm Type

| Event | Alarm Type |
|---------------------------------------|--------------------|
| Tailgating | Visual and Audible |
| Reverse Passing | Visual and Audible |
| Force Accessing | None |
| Climb over Barrier | Visual and Audible |
| Overstay | Visual and Audible |
| Passing Timeout | None |
| Intrusion | Visual and Audible |
| Free Passing Authentication Failed | Visual and Audible |
| Barrier Obstructed | None |

Appendix D. Table of Audio Index Related Content

 **Note**


- If the device is not equipped with access control board, the loudspeaker shall be connected to the main extended interface board.
 - If the device is equipped with access control board, the loudspeaker shall be connected to the access control board. You can set custom broadcasting context via web.
-

| Content |
|----------------------------|
| Climbing over the barrier. |
| Reverse passing. |
| Passing timeout. |
| Intrusion. |
| Tailgating. |
| Overstay. |

Appendix E. Error Code Description

The swing barrier will display the error code on the seven-segment display if error occurred. Refer to the table below to find the description of each number.

| Error Reason | Code | Error Reason | Code |
|--------------------------------|------|--|------|
| The First IR Beam Triggered | 01 | The Thirteenth IR Beam Triggered | 13 |
| The Second IR Beam Triggered | 02 | The Fourteenth IR Beam Triggered | 14 |
| The Third IR Beam Triggered | 03 | Authentication Indicator Board (Entrance) Offline | 49 |
| The Fourth IR Beam Triggered | 04 | Authentication Indicator Board (Exit) Offline | 50 |
| The Fifth IR Beam Triggered | 05 | IR Adapter Board Offline | 51 |
| The Sixth IR Beam Triggered | 06 | Interconnecting Exception | 53 |
| The Seventh IR Beam Triggered | 07 | Not Studying | 54 |
| The Eighth IR Beam Triggered | 08 | Obstruction | 55 |
| The Ninth IR Beam Triggered | 09 | Exceeding Studying Range | 56 |
| The Tenth IR Beam Triggered | 10 | Encoder Exception | 57 |
| The Eleventh IR Beam Triggered | 11 | Motor Exception | 58 |
| The Twelfth IR Beam Triggered | 12 | Extended Interface Board Offline (If the board is not installed, the error code of "49" will appear but the device functions normally) | 59 |



See Far, Go Further